

Mounting instruction





Aircell[®] 7, Ecoflex[®] 7


BNC plug crimp / Item no.: 7375


www.ssb-electronic.com


Required tools:	
1 x	cutter knife
1 x	scissors
1 x	crimping tool
1 x	crimp insert HEX .324" (8,23 mm)
1 x	crimp insert HEX .100" (2,54 mm)
1 x	soldering station + solder


1	
Cut off cable tail right-angled. Slide the crimp sleeve over the end of the cable.	

2	
Remove 12 mm of the outer jacket with the cutter knife.	

3	
Bend the copper braid up at a right angle. Score and remove 4 mm of the copper foil and 4 mm off the foamed dielectric with a cutter knife.	

4	
Push the inner pin onto the conductor and crimp with HEX 0.1 or 0.096 or solder through the hole. Insert the so prepared cable end into the connector housing as far as it will go (click).	

5	
The copper braid is then shortened to the appropriate length using a side cutter. Slide the crimp sleeve up to the stop.	

6	
Crimp the crimp sleeve with the crimping tool. This will clamp the copper braid between the connector housing and the crimp sleeve.	